Towards High-Resolution 3D Anomaly Detection: A Scalable Dataset and Real-Time Framework for Subtle Industrial Defects

Yuqi Cheng^{*1}, Yihan Sun^{*1}, Hui Zhang², Weiming Shen^{† 1}, Yunkang Cao^{† 2}

¹ State Key Laboratory of Intelligent Manufacturing Equipment and Technology, Huazhong University of Science and Technology ² School of Robotics, Hunan University

{yuqicheng, yihansun}@hust.edu.cn, zhanghuihby@126.com, {wshen, caoyunkang}@ieee.org

Abstract

In industrial point cloud analysis, detecting subtle anomalies demands high-resolution spatial data, yet prevailing benchmarks emphasize low-resolution inputs. To address this disparity, we propose a scalable pipeline for generating realistic and subtle 3D anomalies. Employing this pipeline, we developed MiniShift, the inaugural high-resolution 3D anomaly detection dataset, encompassing 2,577 point clouds, each with 500,000 points and anomalies occupying less than 1% of the total. We further introduce Simple3D, an efficient framework integrating Multi-scale Neighborhood Descriptors (MSND) and Local Feature Spatial Aggregation (LFSA) to capture intricate geometric details with minimal computational overhead, achieving real-time inference exceeding 20 fps. Extensive evaluations on MiniShift and established benchmarks demonstrate that Simple3D surpasses state-ofthe-art methods in both accuracy and speed, highlighting the pivotal role of high-resolution data and effective feature aggregation in advancing practical 3D anomaly detection.

HomePage:

https://hustcyq.github.io/MiniShift-Simple3D

Code:

https://github.com/hustCYQ/MiniShift-Simple3D

Datasets:

https://huggingface.co/datasets/ChengYuQi99/MiniShift

Introduction

Despite the exceptional precision of modern manufacturing processes, subtle imperfections often persist, eluding conventional inspection techniques and introducing significant safety risks in downstream applications (Cheng et al. 2024a). Unsupervised point cloud anomaly detection emerges as a compelling strategy for identifying these hard-to-detect flaws (Cao et al. 2024; Wang et al. 2023; Ye et al. 2025). However, the efficacy of such methods is curtailed by their reliance on the widely utilized low-resolution evaluation framework. This dependency creates a pronounced gap between cutting-edge research and the rigorous demands of industrial implementation.

[†]corresponding author. Preprint.

Conventionally, prevalent approaches for 3D anomaly detection begin by selecting a sparse subset of points (typically around 1k) from the original point cloud. These methods encode local neighborhood features to form point groups and assign an anomaly score to each group. Reconstructionbased techniques, such as IMRNet (Li and Xu 2024) and R3D-AD (Zhou et al. 2024), transform each group into representative tokens, which are then reconstructed via a point transformer architecture. The anomaly score is derived by computing the feature-wise discrepancy between the original and reconstructed tokens. In contrast, prototype-based methods like ISMP (Liang et al. 2025) and GLFM (Cheng et al. 2025b) utilize a pre-trained Point Transformer to extract discriminative features from the point groups, and quantify anomalies based on their deviation from learned prototype representations. To generate dense anomaly maps, these sparse group-level scores are interpolated across the full point cloud. However, such interpolation inevitably compromises the spatial granularity necessary for detecting fine-grained defects. For example, an imperfection measuring just 1mm \times 1mm on a 20mm \times 20mm surface becomes almost imperceptible when the point cloud is reduced to 1k points. As illustrated in Figure 1 (a), a subtle protrusion is clearly discernible in the full-resolution 500k point cloud and remains detectable at 8k points, yet it vanishes almost entirely after downsampling to 1k points. This observation highlights the critical need for high-resolution anomaly detection frameworks that preserve spatial fidelity to effectively identify subtle industrial defects.

To detect such subtle anomalies, industrial inspection systems often capture hundreds of thousands to over a million points per object (Cheng et al. 2024b). Although datasets like MVTec 3D-AD(Bergmann et al. 2022), Real3D-AD(Liu et al. 2024), Anomaly-ShapeNet(Li and Xu 2024), and MulSenAD (Li et al. 2024) offer high-resolution point clouds, their anomalies tend to be relatively prominent, contrasting sharply with the exceedingly subtle irregularities encountered in real-world contexts. To bridge this divide between public datasets and practical applications, we propose an innovative pipeline for synthesizing realistic, subtle anomalies within high-resolution point clouds. Additionally, to systematically evaluate detection performance across varying scales, we introduce a multi-level difficulty protocol, classifying anomalies into three tiers—easy, medium,

^{*}These authors contributed equally.



Figure 1: (a) Detecting subtle defects requires high-resolution point clouds to ensure precise localization and accurate identification. (b) The proposed **MiniShift** dataset features high-density point clouds with approximately 500k points per sample, where anomalies occupy less than 1% of the total surface area—posing a significantly more challenging scenario than existing benchmarks. Blue numbers indicate the average number of points per sample, while red numbers denote the anomaly occupancy rate. (c) Visualization of representative samples from MiniShift. Each row corresponds to a different defect category: Areal, Striate, Scratch, and Sphere.

and hard—based on their geometric perturbations and visual detectability. Applying this pipeline to a subset of normal samples from MulSenAD (Li et al. 2024), we establish a novel high-resolution benchmark, **MiniShift**. As illustrated in Figure 1 (b), MiniShift features point clouds with 500k points, far surpassing the resolution of existing datasets (typically below 170k points). Crucially, its anomalies constitute less than 1% of the surface area, necessitating the use of high-resolution spatial features and posing a markedly greater challenge than prior benchmarks.

We conducted an extensive evaluation of state-of-the-art (SOTA) methods on MiniShift using point clouds with 8k points, revealing that these approaches fall short in both performance and efficiency. This inadequacy stems primarily from the limitations of CNN- (He et al. 2016) and ViT- (Zhao et al. 2021) based backbones in applying highresolution point cloud detection: (i) prohibitive computational complexity that scales with input group quantity, and (ii) inaccurate representation of local geometric information. In response, we revisit the utility of handcrafted point cloud descriptors and present a streamlined yet robust baseline, Simple3D, tailored for high-resolution anomaly detection. Simple3D integrates two novel components: the Multiscale Neighborhood Descriptor (MSND) and Local Feature Spatial Aggregation (LFSA). By computing multi-scale descriptors for each point and hierarchically aggregating local spatial features through progressive downsampling, Simple3D achieves a detailed characterization of local geometry. Leveraging lightweight descriptors, it delivers substantially improved accuracy and efficiency over existing methods. Comprehensive experiments affirm that Simple3D attains SOTA performance not only on MiniShift but also across traditional benchmarks, while sustaining real-time inference speeds exceeding 20 FPS. In summary, our contributions are as follows:

- We present MiniShift, a high-resolution 3D anomaly detection dataset comprising 2,577 point clouds, each with 500k points, accompanied by a triple-level difficulty framework to thoroughly assess detection methods.
- We introduce Simple3D, a high-resolution anomaly detection approach with two core components—MSND and LFSA—that markedly enhances the identification of subtle geometric anomalies while preserving computational efficiency.
- Through rigorous experimentation, we demonstrate that Simple3D consistently surpasses existing SOTA methods across MiniShift, and other existing datasets including Real3D-AD, Anomaly-ShapeNet, and MulSenAD, achieving superior accuracy and real-time performance.
- Our systematic analysis underscores the critical role of high-resolution input in precise 3D anomaly detection, revealing that judiciously aggregated local geometric features serve as effective representations for this purpose.

MiniShift Dataset

Pipeline

The development of the MiniShift dataset is illustrated in Figure 2. We commence by extracting 3D data from 12 distinct categories of typical industrial components within the MulSen-AD dataset. These data undergo dense sampling to produce high-resolution point clouds. Subsequently, we propose the Anchor-Guided Geometric Anomaly Synthesis (AG-GAS) method, which facilitates the creation of



Figure 2: **The construction pipeline of MiniShift**. The 3D models are utilized to generate various defects through the proposed AG-GAS framework.

four anomaly types—namely Areal, Striate, Scratch, and Sphere—alongside their associated defect masks. This synthesis is achieved through precise manipulation of anchor point positions and geometric deformation parameters. Additionally, we implement a difficulty protocol, categorizing the dataset into three subsets—easy, medium, and hard—to replicate real-world industrial scenarios characterized by varying detection complexities. Comprehensive details regarding MiniShift, encompassing categories, sample sizes for training and testing sets, and anomaly distributions, are documented in Appendix A.

Anchor-Guided Geometric Anomaly Synthesis

We introduce an automated framework engineered to synthesize realistic and diverse 3D defects, as depicted in Figure 2. The process begins with the random selection of two anchor points, followed by the determination of connecting path points. These path points are then expanded into a local neighborhood, delineating the deformation region wherein a stretching operation generates the defect. Unlike anomaly synthesis methods in R3D (Zhou et al. 2024) and GLFM (Cheng et al. 2025b), which predominantly simulate basic protrusions or depressions within localized circular zones, our framework affords the flexibility to craft defects of diverse shapes and scales through minimal parameter adjustments. This adaptability enhances the simulation of the randomness and intricacy characteristic of industrial defects. The framework is organized into four sequential stages:

Anchor Points Selection: Two anchor points, denoted p_s

and $p_e \in P$, are selected from the input point cloud $P \in \mathbb{R}^{n \times 3}$, comprising *n* points, to regulate the position and span of the synthetic anomaly.

Geodesic Path Computation: As illustrated in Figure 2, we calculate the geodesic path points between the anchor points to support subsequent anomaly generation. Initially, we construct an undirected graph $G = (\{p_i\}, \{e_{ij}\})$ by defining edges $e_{ij} = \langle p_i, p_j \rangle$, where $p_i \in P$ and p_j represents one of the *k* nearest neighbors of p_i within *P*. Dijkstra's algorithm (Frana and Misa 2010) is then applied to ascertain the shortest path π^* between p_s and p_e , yielding the geodesic path point set Γ :

$$\pi^* = \operatorname*{arg\,min}_{\pi \in \Pi(\boldsymbol{p}_s, \boldsymbol{p}_e)} \sum_{\boldsymbol{e}_{ij} \in \pi} w(\boldsymbol{e}_{ij}) \tag{1}$$

$$\boldsymbol{\Gamma} = \{\{\boldsymbol{p}_i, \boldsymbol{p}_j\} \mid \boldsymbol{e}_{ij} \in \pi^*\}$$
(2)

where $\Pi(\mathbf{p}_s, \mathbf{p}_e)$ denotes all possible paths from \mathbf{p}_s to \mathbf{p}_e, π is a path within this set, and $w(\mathbf{e}_{ij})$ is the Euclidean distance between \mathbf{p}_i and \mathbf{p}_j .

Region Expansion: Utilizing the geodesic path Γ as the central axis, we define the mask region M_r through expansion with a control radius r, encompassing points in P that contribute to anomaly generation:

$$\boldsymbol{M}_{r} = \left\{ \boldsymbol{p}_{j} \in \boldsymbol{P} \, \big| \, \|\boldsymbol{p}_{j} - \boldsymbol{p}_{i}\| < r, \forall \boldsymbol{p}_{i} \in \boldsymbol{\Gamma} \right\}$$
(3)

Geometric Distortion: The distortion direction is established by computing the average normal vector \bar{n}_{avg} of points within M_r :

$$\bar{\boldsymbol{n}}_{avg} = \frac{\bar{\boldsymbol{n}}}{\|\bar{\boldsymbol{n}}\|_2}, \quad \bar{\boldsymbol{n}} = \frac{1}{|\boldsymbol{M}_r|} \sum_{\boldsymbol{p}_j \in \boldsymbol{M}_r} \boldsymbol{n}_j$$
(4)

where n_j is the normal vector of point p_j , and $|M_r|$ indicates the number of points in M_r . The distortion, controlled by a parameter $dir \in \{1, -1\}$ (1 for protrusion, -1 for depression), shifts points in M_r by a distance d along \bar{n}_{avg} . To ensure smoothness, the stretching distance is scaled according to proximity to the central axis, yielding the anomaly point:

$$\boldsymbol{p}_{j}' = \boldsymbol{p}_{j} + dir \cdot \bar{\boldsymbol{n}}_{avg} \cdot \left(1 - \frac{\boldsymbol{d}_{j}}{\boldsymbol{d}_{\max}}\right) \cdot d, \quad \boldsymbol{d}_{\max} = \max_{\boldsymbol{p}_{i} \in \boldsymbol{M}_{r}} \boldsymbol{d}_{i}$$
(5)

where $oldsymbol{d}_j = \min_{oldsymbol{p}_m \in oldsymbol{\Gamma}} \|oldsymbol{p}_j - oldsymbol{p}_m\|.$

Through precise parameterization, our framework synthesizes diverse defect types for the MiniShift dataset, selecting four representative categories—Areal, Striate, Scratch, and Sphere—reflecting prevalent industrial defect patterns. Areal and Striate defects, marked by subtle distortions, commonly result from uneven mechanical stress or thermal gradients in machining and casting. Conversely, Scratch and Sphere anomalies, with minimal surface coverage, typically arise from impacts or friction during milling, handling, or assembly. We generate 30 unique samples per category and defect type. Further dataset specifics are provided in Appendix A, with comparisons to other datasets in Appendix B.

Difficulty Protocol

To tackle the dual objectives of industrial inspection realism and algorithmic performance evaluation, we devise a difficulty protocol that classifies synthesized anomalies into three tiers-easy, medium, and hard-based on geometric saliency and perceptual visibility. Large-scale deformations and expansive defects are readily detectable by human inspectors and automated systems, whereas subtle anomalies (e.g., minor protrusions or micro-scratches) exhibit higher oversight rates. The easy subset features anomalies with prominent distortions or broad spatial extent, facilitating identification, while the hard subset includes minute or nearly imperceptible defects, mirroring critical industrial edge cases prone to missed detection. Figure 1 (c) showcases anomaly samples across difficulty levels, with additional visualizations in Appendix G. This protocol augments the dataset's hierarchical representation of real-world defect complexity and establishes a benchmark for assessing algorithmic robustness and generalization.

The parameters governing anomaly difficulty are outlined in Table 1, adjusted via the ranges of α , β , and γ , defined as:

$$\alpha = l/D, \quad \beta = r/D, \quad \gamma = d/D, \tag{6}$$

where $D = ||\max(\mathbf{P}) - \min(\mathbf{P})||_2$ represents the point cloud's bounding box diagonal, l is the geodesic distance between \mathbf{p}_s and \mathbf{p}_e .

Table 1: **Difficulty Protocol**. Color-filled cells highlight the key indicators that determine the difficulty of the category.

Protoco	ol	Easy	Medium	Hard		
	α	$0.05 \sim 0.1$	$0.05 \sim 0.1$	$0.05 \sim 0.1$		
Areal	β	$0.04 \sim 0.07$	$0.04 \sim 0.07$	$0.04 \sim 0.07$		
	γ	$5\times 10^{-3}\sim 7\times 10^{-3}$	$3\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 3\times 10^{-3}$		
	α	$0.02 \sim 0.1$	$0.02 \sim 0.1$	$0.02 \sim 0.1$		
Striate	β	$0.01 \sim 0.03$	$0.01 \sim 0.03$	$0.01 \sim 0.03$		
	γ	$5\times 10^{-3}\sim 7\times 10^{-3}$	$3\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 3\times 10^{-3}$		
	α	$0.3 \sim 0.4$	$0.2 \sim 0.3$	$0.1 \sim 0.2$		
Scratch	β	$3\times 10^{-3}\sim 4\times 10^{-3}$	$2\times 10^{-3}\sim 3\times 10^{-3}$	$1\times 10^{-3}\sim 2\times 10^{-3}$		
	γ	$1\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 5\times 10^{-3}$		
	α	$< 1 \times 10^{-3}$	$< 1 \times 10^{-3}$	$< 1 \times 10^{-3}$		
Sphere	β	$7\times 10^{-3}\sim 9\times 10^{-3}$	$5\times 10^{-3}\sim 7\times 10^{-3}$	$3\times 10^{-3}\sim 5\times 10^{-3}$		
	γ	$1\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 5\times 10^{-3}$	$1\times 10^{-3}\sim 5\times 10^{-3}$		

Simple3D Method

Overview

To address the challenges posed by high-resolution detection, we present Simple3D, a simple yet effective framework. The overall architecture of this framework is illustrated in Figure 3. Unlike existing approaches that commonly utilize CNNs or ViTs for point cloud feature extraction, resulting in prohibitive computational costs for highresolution detection, our method focuses on extracting local point features using handcrafted descriptors. These features are subsequently aggregated across spatial hierarchies to enhance the detection of anomalies. Simple3D employs a prototype-based detection mechanism, where anomaly scores are assigned by quantifying the deviations of features from established normal prototypes.

Multi-Scale Neighborhood Description (MSND)

Let the input point cloud be denoted by $P \in \mathbb{R}^{n \times 3}$, where n represents the total number of points. For each point $p_i \in P$, we identify its k nearest neighbors to construct a point set R_i . To harness the complementary information inherent in local point distributions across various neighborhood scales, we employ multiple neighbor counts k_1, k_2, \ldots, k_m , thereby generating a sequence of point sets $R_{i1}, R_{i2}, \ldots, R_{im}$. Subsequently, a local feature operator f is applied to extract feature descriptors from each point set. These descriptors are concatenated to form the multi-scale local feature representation F_i of p_i :

$$\boldsymbol{F}_{i} = \operatorname{Concat}(\boldsymbol{R}_{i1}, \boldsymbol{R}_{i2}, \dots, \boldsymbol{R}_{im})$$
(7)

Local Feature Spatial Aggregation (LFSA)

To further refine the feature representation, we randomly sample t points from P and aggregate the MSND within their respective neighborhoods. This process yields enhanced point features that possess both an expanded receptive field and enriched local geometric information. Specifically, let the sampled points be denoted as p_{s_j} for $0 \le j \le t$ and $0 \le s_j \le n$, with the neighbor count specified as k_L . The enhanced point feature $F_{s_j}^A$ for p_{s_j} is computed as:

$$\boldsymbol{F}_{s_j}^A = \frac{1}{k_L} \sum_{\boldsymbol{F} \in \boldsymbol{R}_{s_j k_L}} \boldsymbol{F}$$
(8)

Anomaly Detection

The enhanced point features derived from normal point clouds are utilized to establish a normal prototype set $S = \{F_{s_1}^A, F_{s_2}^A, \dots, F_{s_t}^A\}$. For the enhanced point features F_{test}^A of test point clouds, deviations from this normal prototype set are interpreted as anomaly scores. The point-wise anomaly scores A and the object-wise anomaly score ξ are determined by:

$$\boldsymbol{A} = \|\boldsymbol{F}_{\text{test}}^{A} - \boldsymbol{F}^{*}\| \tag{9}$$

$$\boldsymbol{\xi} = \max(\boldsymbol{A}) \tag{10}$$

where $oldsymbol{F}^* = \min_{s \in oldsymbol{\mathcal{S}}} \|s - oldsymbol{F}^A_{ ext{test}}\|.$

Experiment

Experimental Setups

Datasets: Our experimental evaluation encompasses the proposed **MiniShift** dataset alongside three established public benchmarks: **Real3D-AD** (Liu et al. 2024), **Anomaly-ShapeNet** (Li and Xu 2024), and **MulSen-AD** (Li et al. 2024). We refer you to Appendix **B** for more details about these datasets.

Implementation Details: For point cloud feature extraction, our approach utilizes the handcrafted descriptor FPFH (Rusu, Blodow, and Beetz 2009) due to its efficient CUDA-accelerated implementation available in Open3D (Zhou, Park, and Koltun 2018). The multi-scale ranges are set to 40, 80, and 120 by default, and the number



Figure 3: **Framework of the proposed method, Simple3D.** High-resolution point clouds undergo initial processing to derive multi-scale neighborhood descriptors. These descriptors are then spatially aggregated to yield enhanced point cloud features. Simple3D utilizes a prototype-based approach to facilitate both object-wise and point-wise anomaly detection.

Table 2: **Quantitative Results on MiniShift**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$\begin{array}{c} \text{Method} \rightarrow \\ \text{Level} \downarrow \end{array}$	PatchCore-FP CVPR'22	PatchCore-PM CVPR'22	PatchCore-PB CVPR'22	R3D-AD ECCV'24	GLFM TASE'25	Simple3D Ours
Easy	<u>68.3</u> /56.5	57.2/57.3	55.5/51.6	56.3/48.3	57.7/ <u>67.7</u>	75.6/77.3
Medium	<u>65.6</u> /54.1	55.8/52.6	46.6/50.3	50.8/50.7	55.0/ <u>57.3</u>	68.6/65.5
Hard	<u>61.4</u> /51.1	54.3/52.0	52.9/50.8	50.1/50.6	52.8/ <u>52.7</u>	61.6/56.3
ALL	<u>65.1</u> /53.7	55.9/54.1	50.0/51.4	53.6/49.8	55.8/ <u>58.7</u>	68.6/66.2

of aggregation points is configured to 128. All experiments are conducted on NVIDIA A100 GPUs.

Evaluation Metrics: To assess the efficacy of our method, we employ the widely recognized Area Under the Receiver Operating Characteristic curve (AUROC) metric. Specifically, we calculate both object-wise AUROC (O-ROC) and point-wise AUROC (P-ROC) to gauge performance across the four datasets.

Comparison Methods: Our proposed method is rigorously benchmarked against a diverse array of recent SOTA approaches. These include prototype-based methods such as PatchCore (Roth et al. 2022; Horwitz and Hoshen 2023), BTF (Horwitz and Hoshen 2023), M3DM (Wang et al. 2023), CPMF (Cao, Xu, and Shen 2024), Reg3D-AD (Liu et al. 2024), Group3AD (Zhu et al. 2024), and GLFM (Cheng et al. 2025b); reconstruction-based methods like R3D-AD (Zhou et al. 2024), IMRNet (Li and Xu 2024), and MC3D-AD (Cheng et al. 2025a); and the regressionbased method PO3AD (Ye et al. 2025). Notably, M3DM and PatchCore are evaluated with various feature types, denoted as "-FP" for FPFH (Rusu, Blodow, and Beetz 2009), "-PM" for PointMAE (Pang et al. 2023), "-PB" for Point-BERT (Yu et al. 2022).

Benchmarking Results on MiniShift

The quantitative assessment of all competing methods on MiniShift is delineated in Table 2. Our approach consistently surpasses all baseline methods across diverse difficulty tiers, underscoring its exceptional generalization and robustness. As the dataset complexity escalates, existing methods man-



Figure 4: Visualization of our point-wise anomaly detection results on MiniShift. From top to bottom: input point clouds, ground truths, anomaly maps.

ifest a marked deterioration in performance, particularly in the most arduous scenarios, where their efficacy in both O-ROC and P-ROC metrics approaches futility. Conversely, while our method also incurs a modest decline in performance, it sustains a decisive and substantial advantage over all rival techniques. This superior performance is chiefly ascribed to two pivotal components of our methodology, which enable the extraction of highly discriminative and expressive features. As a result, our approach adeptly discerns even the most subtle and intricate anomalies that elude detection by other methods.

The qualitative analysis, as depicted in Figure 4, corroborates these quantitative outcomes. Our method, Simple3D, produces anomaly maps of remarkable sharpness and precision across multiple categories, even amidst intricate and challenging conditions. In stark contrast, the majority of baseline methods struggle to delineate defects from the background effectively, thereby underscoring the critical necessity of high-resolution representations and meticulous local feature descriptions for proficient anomaly detection. Detailed per-category evaluations and additional qualitative illustrations are furnished in Appendix C and Appendix H, respectively.

Table 3: Quantitative Results on Real3D-AD, Anomaly-ShapeNet and MulSen-AD. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$\begin{array}{l} \text{Method} \rightarrow \\ \text{Real3D-AD} \end{array}$	CPMF	Reg3D-AD	Group3AD	IMRNet	ISMP	GLFM	PO3AD	MC3D-AD	Simple3D
	PR'24	NeurIPS'23	ACM MM'24	CVPR'24	AAAI'25	TASE'25	CVPR'25	IJCAI'25	Ours
O-ROC/P-ROC	62.5/75.9	70.4/70.5	75.1/73.5	72.5/-	76.7/ <u>83.6</u>	75.0/76.7	76.5/-	<u>78.2</u> /76.8	80.4/92.3
$\begin{array}{l} \text{Method} \rightarrow \\ \text{Anomaly-ShapeNet} \end{array}$	M3DM-PM	CPMF	Reg3D-AD	IMRNet	ISMP	GLFM	PO3AD	MC3D-AD	Simple3D
	CVPR'23	PR'24	NeurIPS'23	CVPR'24	AAAI'25	TASE'25	CVPR'25	IJCAI'25	Ours
O-ROC/P-ROC	51.1/54.9	55.9/-	57.2/-	66.1/65.0	75.7/69.1	61.9/74.5	83.9/ <u>89.8</u>	<u>84.2</u> /74.8	86.0/92.9
$\begin{array}{l} \text{Method} \rightarrow \\ \text{MulSen-AD} \end{array}$	M3DM-PM	M3DM-PB	PatchCore-FP	PatchCore-FP-R	PatchCore-PM	IMRNet	Reg3D-AD	GLFM	Simple3D
	CVPR'23	CVPR'23	CVPR'22	CVPR'22	CVPR'22	CVPR'24	NeurIPS'23	TASE'25	Ours
O-ROC/P-ROC	62.8/58.7	70.5/61.1	<u>86.0</u> /64.0	83.3/62.0	84.0/60.5	60.1/46.7	74.9/64.1	78.5/66.5	88.2/80.3



Figure 5: Visualization of our point-wise anomaly detection results on Real3D-AD, Anomaly-ShapeNet, and MulSen-AD. From top to bottom: input point clouds, ground truths, anomaly maps.

Benchmarking Results on Existing Datasets

To further ascertain the efficacy of Simple3D, we extend our evaluation to three prominent public benchmarks: Real3D-AD, Anomaly-ShapeNet, and MulSen-AD. The outcomes are encapsulated in Table 3. Simple3D uniformly sets new SOTA benchmarks across all datasets for both O-ROC and P-ROC metrics. Moreover, our method exhibits robust per-category performance and precise localization of finegrained anomalies, thereby affirming its generalizability and discriminative prowess across a spectrum of 3D anomaly types.

Real3D-AD: On the Real3D-AD dataset, Simple3D attains scores of 80.4% and 92.3% for O-ROC and P-ROC, respectively, thereby eclipsing prior SOTA methods such as MC3D-AD and ISMP by margins of 2.2% and 8.7% in the respective metrics. The comprehensive per-category analysis, detailed in Appendix D, reveals that Simple3D secures the highest object-wise or point-wise performance in 10 out of 12 categories, thereby attesting to its efficacy. Particularly noteworthy is the near-perfect detection achieved in the Diamond (100%/99.0%) and Car (98.1%/99.2%) categories.

Anomaly-ShapeNet: For the Anomaly-ShapeNet dataset, Simple3D records O-ROC and P-ROC scores of 86.0% and 92.9%, respectively. Significantly, our method not only outperforms MC3D-AD by 1.8% in O-ROC but also demonstrates a substantial enhancement of 18.1% in P-ROC. The per-category breakdown, presented in Appendix E, indicates that Simple3D achieves superior performance in 35 out of 40 categories and attains complete detection in 5 categories, further solidifying its preeminence.

MulSen-AD: On the MulSen-AD dataset, Simple3D establishes a new SOTA benchmark with scores of 88.3% and 80.3% for O-ROC and P-ROC, respectively, thereby surpassing the previous best by 2.2% and 16.2%. The percategory evaluation, as documented in Appendix F, reveals that our method attains the highest point-wise performance in 12 out of 15 categories.

Qualitative Results and Analysis: The qualitative results, as showcased in Figure 5, exemplify the adeptness of Simple3D in precisely localizing subtle anomalies across the Real3D-AD, Anomaly-ShapeNet, and MulSen-AD datasets. These visualizations accentuate the method's superior detection capabilities, particularly when juxtaposed with the shortcomings exhibited by competing approaches.

Ablation Study

To elucidate the impact of MSND and LFSA, we undertake a thorough ablation study across all four datasets. The results, as tabulated in Table 4, demonstrate that both components invariably augment detection performance, yielding substantial gains across all evaluated metrics.

Analysis on Detection Resolution To delve deeper into the influence of detection resolution on efficacy, we assess



Figure 6: Influence of detection resolution t (First Row) and aggregated neighborhood point number k_L (Second Row). The left four figures show the performance on datasets Real3D-AD, Anomaly-ShapeNet, MulSen-AD, and MiniShift, while the last one shows the Frames Per Second (FPS), as the sampling resolution t varies from 256 (2⁸) to 8192 (2¹³) and aggregated neighborhood point number k_L varies from 8 (2³) to 128 (2⁸). The FPS is statistically analyzed on the Anomaly-ShapeNet.

Table 4: Ablation results of MSND and LFSA between four datasets.

MSND LFSA	X X	✓ ×	×	<i>J</i>
Real3D-AD	74.2/76.9	78.1/85.3	79.8/90.0	80.4/92.3
Anomaly-ShapeNet	78.8/77.0	83.8/85.6	85.7/90.4	86.0/92.9
MulSen-AD	85.1/66.2	86.8/70.7	87.1/77.3	88.2/80.3
MiniShift	67.2/56.7	67.8/57.9	67.4/63.1	68.6/66.2

our method across a spectrum of resolutions ranging from 2^8 to 2^{13} , while maintaining a fixed aggregation point count of 16, utilizing the four benchmark datasets. The findings, depicted in the first row of Figure 6, reveal a consistent enhancement in all evaluation metrics concomitant with increased resolution across all datasets. Notably, at resolutions exceeding 2^{12} , our method surpasses the performance of prior SOTA techniques. These observations underscore the pivotal importance of high-resolution representations in bolstering the accuracy and dependability of anomaly detection.

Analysis on Number of Aggregated Points Simple3D incorporates LFSA to expand the receptive field of local features for better feature distinguishability. To quantify the effect of the aggregated point count on detection performance, we systematically vary the neighborhood size from 2^3 to 2^8 points, while keeping the input resolution constant at 4k points. The outcomes, illustrated in the second row of Figure 6, demonstrate a uniform improvement in performance metrics across all datasets as the number of aggregated points increases. These findings accentuate the indispensable role of meticulous local feature description in 3D anomaly detection, with our approach occasionally outperforming features derived from learned 3D backbones. Analysis on Runtime The runtime analysis, as presented in Figure 6, elucidates the influence of resolution and the number of aggregation points on detection speed. Notably, at a resolution of 4k points, Simple3D not only surpasses prior SOTA methods in performance but also sustains a detection speed exceeding 20 FPS, markedly outpacing all competing approaches. This real-time processing capability is of paramount significance for practical applications, such as industrial inspection.

Conclusion

We present MiniShift, a novel benchmark for highresolution 3D anomaly detection, constructed via a controllable synthetic pipeline that scalably generates realistic and subtle surface defects. Our evaluation protocol classifies anomalies into three difficulty levels based on geometric saliency and perceptual visibility, ensuring a comprehensive assessment aligned with real-world industrial complexities. Current SOTA methods struggle to balance accuracy and efficiency in high-resolution contexts. To overcome this, we propose Simple3D, a lightweight yet potent method enabling real-time, fine-grained anomaly detection in dense point clouds. Rigorous experiments on MiniShift and datasets such as Real3D-AD, Anomaly-ShapeNet, and MulSenAD reveal that Simple3D achieves SOTA performance in both accuracy and speed, emphasizing the essential role of high-resolution representations in detecting minute defects. We assert that MiniShift and Simple3D lay robust groundwork for future advancements in high-resolution 3D anomaly detection.

Future Directions: Leveraging our scalable anomaly generation pipeline, we aim to construct a large-scale, diverse dataset for 3D anomaly detection, facilitating the development of foundational models adept at identifying subtle anomalies across varied categories for seamless industrial integration.

References

Bergmann, P.; Jin, X.; Sattlegger, D.; and Steger, C. 2022. The mytec 3d-ad dataset for unsupervised 3d anomaly detection and localization. *Proceedings of the 17th International Joint Conference on Computer Vision, Imaging and Computer Graphics Theory and Applications*, 5: 202–213. Doi: 10.5220/0010865000003124.

Cao, Y.; Xu, X.; and Shen, W. 2024. Complementary pseudo multimodal feature for point cloud anomaly detection. *Pattern Recognition*, 156: 110761.

Cao, Y.; Zhang, J.; Frittoli, L.; Cheng, Y.; Shen, W.; and Boracchi, G. 2024. Adaclip: Adapting clip with hybrid learnable prompts for zero-shot anomaly detection. In *European Conference on Computer Vision*, 55–72. Springer.

Cheng, J.; Gao, C.; Zhou, J.; Wen, J.; Dai, T.; and Wang, J. 2025a. MC3D-AD: A Unified Geometry-aware Reconstruction Model for Multi-category 3D Anomaly Detection. *IJCAI*.

Cheng, Y.; Cao, Y.; Wang, D.; Shen, W.; and Li, W. 2025b. Boosting Global-Local Feature Matching via Anomaly Synthesis for Multi-Class Point Cloud Anomaly Detection. *IEEE Transactions on Automation Science and Engineering*, 1–1.

Cheng, Y.; Cao, Y.; Xie, G.; Lu, Z.; and Shen, W. 2024a. Towards Zero-shot Point Cloud Anomaly Detection: A Multi-View Projection Framework. *arXiv preprint arXiv:2409.13162*.

Cheng, Y.; Li, W.; Jiang, C.; Wang, D.; Xing, H.; and Xu, W. 2024b. MVGR: Mean-Variance Minimization Global Registration Method for Multi-view Point Cloud in Robot Inspection. *IEEE Transactions on Instrumentation and Measurement*, 1–1.

Frana, P. L.; and Misa, T. J. 2010. An interview with edsger w. dijkstra. *Communications of the ACM*, 53(8): 41–47.

He, K.; Zhang, X.; Ren, S.; and Sun, J. 2016. Deep residual learning for image recognition. In *Proceedings of the IEEE conference on computer vision and pattern recognition*, 770–778.

Horwitz, E.; and Hoshen, Y. 2023. Back to the feature: classical 3d features are (almost) all you need for 3d anomaly detection. In *Proceedings of the IEEE/CVF Conference on Computer Vision and Pattern Recognition*, 2967–2976.

Li, W.; and Xu, X. 2024. Towards Scalable 3D Anomaly Detection and Localization: A Benchmark via 3D Anomaly Synthesis and A Self-Supervised Learning Network. 2024 *IEEE/CVF Conference on Computer Vision and Pattern Recognition (CVPR).*

Li, W.; Zheng, B.; Xu, X.; Gan, J.; Lu, F.; Li, X.; Ni, N.; Tian, Z.; Huang, X.; Gao, S.; et al. 2024. Multi-Sensor Object Anomaly Detection: Unifying Appearance, Geometry, and Internal Properties. *arXiv preprint arXiv:2412.14592*.

Liang, H.; Xie, G.; Hou, C.; Wang, B.; Gao, C.; and Wang, J. 2025. Look Inside for More: Internal Spatial Modality Perception for 3D Anomaly Detection. *AAAI*.

Liu, J.; Xie, G.; Li, X.; Wang, J.; Liu, Y.; Wang, C.; Zheng, F.; et al. 2024. Real3D-AD: A Dataset of Point Cloud Anomaly Detection. In *Thirty-seventh Conference on Neural Information Processing Systems Datasets and Benchmarks Track*, volume 36.

Pang, Y.; Tay, E. H. F.; Yuan, L.; and Chen, Z. 2023. Masked Autoencoders for 3D Point Cloud Self-supervised Learning. *World Scientific Annual Review of Artificial Intelligence*, 1: 2440001.

Roth, K.; Pemula, L.; Zepeda, J.; Schölkopf, B.; Brox, T.; and Gehler, P. 2022. Towards total recall in industrial anomaly detection. In *Proceedings of the IEEE/CVF Conference on Computer Vision and Pattern Recognition*, 14318–14328. Doi: 10.1109/CVPR52688.2022.01392.

Rusu, R. B.; Blodow, N.; and Beetz, M. 2009. Fast point feature histograms (FPFH) for 3D registration. In 2009 *IEEE international conference on robotics and automation*, 3212– 3217. IEEE.

Wang, Y.; Peng, J.; Zhang, J.; Yi, R.; Wang, Y.; and Wang, C. 2023. Multimodal industrial anomaly detection via hybrid fusion. In *Proceedings of the IEEE/CVF Conference on Computer Vision and Pattern Recognition*, 8032–8041.

Ye, J.; Zhao, W.; Yang, X.; Cheng, G.; and Huang, K. 2025. Po3ad: Predicting point offsets toward better 3d point cloud anomaly detection. In *Proceedings of the Computer Vision and Pattern Recognition Conference*, 1353–1362.

Yu, X.; Tang, L.; Rao, Y.; Huang, T.; Zhou, J.; and Lu, J. 2022. Point-bert: Pre-training 3d point cloud transformers with masked point modeling. In *Proceedings of the IEEE/CVF conference on computer vision and pattern recognition*, 19313–19322.

Zhao, H.; Jiang, L.; Jia, J.; Torr, P. H.; and Koltun, V. 2021. Point transformer. In *Proceedings of the IEEE/CVF international conference on computer vision*, 16259–16268.

Zhou, Q.-Y.; Park, J.; and Koltun, V. 2018. Open3D: A modern library for 3D data processing. *arXiv preprint arXiv:1801.09847*.

Zhou, Z.; Wang, L.; Fang, N.; Wang, Z.; Qiu, L.; and Zhang, S. 2024. R3D-AD: Reconstruction via Diffusion for 3D Anomaly Detection. In *European Conference on Computer Vision (ECCV)*.

Zhu, H.; Xie, G.; Hou, C.; Dai, T.; Gao, C.; Wang, J.; and Shen, L. 2024. Towards High-resolution 3D Anomaly Detection via Group-Level Feature Contrastive Learning. *ACM Multimedia* (*ACM MM*).

Appendix

The supplementary material includes the following sections to provide additional support for the main manuscript:

- Sec. A: Details about MiniShift
- Sec. B: Dataset Comparison
- Sec. C: Detailed Results on MiniShift
- Sec. D Detailed Results on Real3D-AD
- Sec. E Detailed Results on Anoamly-ShapeNet
- Sec. F Detailed Results on MulSen-AD
- Sec. G More Visualization of MiniShift
- Sec. H More Qualitative Results

A. Details about MiniShift

Table 5 presents the detailed data distribution for each category in MiniShift. MiniShift comprises 12 categories (Capsule, Cube, Spring pad, Screw, Screen, Piggy, Nut, Flat pad, Plastic cylinder, Button cell, Toothbrush, and Light.), with a total of 2577 samples. Specifically, we selected 10 3D samples from the corresponding training data of MulSenAD for synthetic anomaly generation, while the remaining samples are used as the our training set. These 10 samples are utilized to generate 120 anomalous instances to form the testing set, with 30 samples for each defect type. The testing set also includes 10 normal samples from the MulSen testing set, resulting in a total of 130 test samples for each category.

B. Dataset Comparison

Statistical comparisons between MiniShift and existing 3D AD datasets, are summarized in Table 6, highlighting that our dataset offers the highest spatial resolution (500,000 points significantly higher than other datasets) and exhibits the lowest anomaly coverage (< 1.0% significantly more challenging than other datasets).

C. Detailed Results on MiniShift

Tabel 7 shows the detailed performance of each category. Simple3D achieves the best performance in 10 of 12 categories, and is significantly superior to other methods in the average performance. The results of the three subsets also consistently support the superiority of our method, as shown in Table Tabel 8, Tabel 9, and Tabel 10. Nevertheless, the O-ROC/P-ROC less than 70% highlights the challenge of detecting subtle defects.

D. Detailed Results on Real3D-AD

Table 11 presents the quantitative comparison on the Real3D-AD dataset. Simple3D, achieves the best performance across the board, with an average O-ROC of 80.4% and P-ROC of 92.3%, outperforming all existing baselines. Notably, Simple3D ranks first in 7 out of 12 categories for P-ROC, including Car (99.2%), Diamond (99.0%), Seahorse (94.2%), and Fish (96.2%), while maintaining competitive or top-tier results in most other classes.

E. Detailed Results on Anoamly-ShapeNet

Quantitative comparison on the Anoamly-ShapeNet dataset is provided in Tabel 12. Compared to recent SOTA methods such as MC3D-AD and PO3AD, Simple3D exhibits superior object- and point-level detection and robustness across diverse object categories. For example, although MC3D-AD performs well in O-ROC for some categories, its average P-ROC scores often lag behind, highlighting weaker spatial precision. In contrast, Simple3D delivers consistently high P-ROC values, validating its strength in dense and fine-grained anomaly perception.

F. Detailed Results on MulSen-AD

Quantitative comparison on the MulSen-AD dataset is shown in Tabel 13. Simple3D achieves the best performance with an average O-ROC of 88.2% and P-ROC of 80.3%, outperforming all existing baselines. Methods like GLFM, while effective in certain categories, fall short in generalization, with average P-ROC below 70%. This reinforces the capability of Simple3D to generalize well across varying shapes, scales, and defect patterns, without reliance on complex augmentation or task-specific tuning.

G. More Visualization of MiniShift

Figure 7 illustrates representative samples from our proposed dataset MiniShift, covering all four synthetic defect types (Areal, Striate, Scratch, and Sphere) across 12 object categories. For each defect type, the top row presents high-resolution point cloud renderings of the defective instances, while the corresponding bottom row (GT) displays the ground truth annotations highlighting the exact defect regions. Red boxes denote zoomed-in views that reveal localized structural anomalies in finer detail. This visualization comprehensively demonstrates the diversity of object geometries and defect manifestations, validating the dataset's capacity to support subtle 3D anomaly detection.

H. More qualitative results

Figure 8 presents qualitative comparisons of point-wise anomaly detection results across MiniShift. From top to bottom, we visualize the input point clouds, the ground-truth annotations (GT), and anomaly maps produced by competing methods, including PatchCore (including the features from FPFH, PointMAE, and PointBert), GLFM, R3D-AD, and our proposed Simple3D. Compared to existing methods, Simple3D consistently produces highly localized and sharply bounded anomaly maps, showing strong alignment with ground-truth defect regions. For example, on complex geometries such as the Screw, Plastic Cylinder, or Toothbrush, Simple3D effectively isolates subtle structural defects that are either missed or diffusely detected by other baselines. This visual evidence reinforces Simple3D's ability to capture discriminative local descriptors, outperforming prior SOTA methods in both accuracy and interpretability across diverse defect scenarios.

Category	#Training			#Testing	5		Total	Resolution
	Normal	Normal	Areal	Striate	Scratch	Sphere		
Capsule	54	10	30	30	30	30	184	500,000
Cube	100	10	30	30	30	30	230	500,000
Spring pad	76	10	30	30	30	30	206	500,000
Screw	80	10	30	30	30	30	210	500,000
Screen	59	10	30	30	30	30	189	500,000
Piggy	100	10	30	30	30	30	230	500,000
Nut	108	10	30	30	30	30	238	500,000
Flat pad	80	10	30	30	30	30	210	500,000
Plastic cylinder	80	10	30	30	30	30	210	500,000
Button cell	80	10	30	30	30	30	210	500,000
Toothbrush	100	10	30	30	30	30	230	500,000
Light	100	10	30	30	30	30	230	500,000

Table 5: Detailed data distribution for each category in MiniShift.

Table 6: **Statistical comparisons between MiniShift and existing 3D AD datasets.** MiniShift dataset offers the highest spatial resolution and exhibits the lowest anomaly coverage, posing greater challenges for fine-grained anomaly detection.

Dataset	#Category	#	Point Cloud	Resolution	Ratio	
		Normal	Abnormal	Total		
MVTec 3D-AD	10	2,904	948	3,852	26,532	1.8%
Real3D-AD	12	652	602	1,254	169,022	2.7%
Anomaly-ShapeNet	40	160	1,440	1,600	58,604	2.4%
MulSen-AD	15	1,541	494	2,035	29,818	4.2%
MiniShift	12	1137	1,200	2577	500,000	0.99%

Table 7: **Quantitative Results on MiniShift-ALL**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$\begin{array}{l} \text{Method} \rightarrow \\ \text{Category} \downarrow \end{array}$	PatchCore-FP CVPR'22	PatchCore-PM CVPR'22	PatchCore-PB CVPR'22	R3D-AD ECCV'24	GLFM TASE'25	Simple3D Ours
Capsule	<u>88.0</u> /58.4	32.4/54.6	27.2/51.1	60.0/51.3	41.2/ <u>69.4</u>	92.9/80.6
Spring pad	68.9 /53.4	53.2/ <u>55.0</u>	41.0/52.8	32.9/50.3	48.8/ <u>65.5</u> 53.4/54.5	<u>68.7</u> / 63.1
Screw	25.0/ <u>56.0</u>	59.2/54.9	<u>67.2</u> /51.3	63.9/48.7	68.2/53.4	23.2/ 64.6
Screen	70.2/53.3	63.5/52.8	54.0/50.2	42.9/47.2	63.9/ 66.8	<u>70.0/57.5</u>
Piggy	61.3/ <u>55.5</u>	58.4/53.8	50.3/52.4	36.0/49.7	<u>63.8</u> /53.4	67.4/67.5
Nut	<u>69.2</u> /54.5	58.0/55.1	43.2/53.0	66.3/53.7	49.4/ <u>56.6</u>	76.9/73.1
Flat pad	60.7/54.1	59.9/ <u>57.8</u>	60.9/52.7	59.3/49.5	<u>67.7</u> /57.6	68.8/61.8
Plastic cylinder	<u>81.2</u> /54.8	77.7/53.0	60.3/51.6	70.2/50.7	63.5/ <u>58.9</u>	83.2/70.3
Button cell	<u>86.2</u> /57.4	64.3/52.7	51.1/48.4	43.7/50.3	72.0/62.3	90.0/73.2
Toothbrush	48.8/46.7	55.1/ 56.7	49.0/ <u>55.2</u>	66.3/39.2	44.1/47.8	<u>66.1</u> /45.5
Light	59.8 /47.7	51.2/51.6	51.3/50.5	48.2/53.0	33.0/ <u>58.2</u>	<u>54.2</u> /70.1
Mean	<u>65.1</u> /53.7	55.9/54.1	50.0/51.4	53.6/49.8	55.8/ <u>58.7</u>	68.6/66.2

Table 8: **Quantitative Results on MiniShift-easy**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$Method \rightarrow$	PatchCore-FP	PatchCore-PM	PatchCore-PB	R3D-AD	GLFM	Simple3D
Category \downarrow	CVPR'22	CVPR'22	CVPR'22	ECCV'24	TASE'25	Ours
Capsule	<u>99.8</u> /66.9	46.0/56.7	43.2/52.9	50.5/49.3	61.2/ <u>87.4</u>	100.0/97.1
Cube	62.8/54.2	44.8/52.9	<u>64.8</u> /46.8	41.8/49.3	47.0/74.1	72.5/78.2
Spring pad	<u>71.0</u> /54.7	43.8/62.3	46.5/52.3	53.5/51.6	41.5/59.1	72.2/70.2
Screw	25.0/53.8	<u>65.5</u> /57.2	56.2/55.4	61.8/52.6	69.0/ <u>58.3</u>	25.2/ 73.2
Screen	69.5/55.2	67.2/54.4	54.8/47.6	61.0/43.1	76.7/81.4	73.0/67.1
Piggy	62.0/56.8	70.2/56.9	62.5/55.3	<u>69.8</u> /46.3	54.8/62.3	69.8/78.4
Nut	<u>74.0</u> /56.4	60.7/57.1	49.2/52.1	60.8/47.4	45.0/ <u>61.7</u>	85.8/87.0
Flat pad	62.5/55.6	<u>64.5</u> /62.9	51.0/51.1	59.5/50.1	63.8/ <u>63.9</u>	77.8/68.2
Plastic cylinder	<u>84.5</u> /55.8	72.2/55.6	69.5/49.8	45.8/49.9	70.0/ <u>68.4</u>	91.5/85.1
Button cell	<u>95.0</u> /67.4	62.8/57.7	50.5/49.1	50.0/50.2	65.0/ <u>74.2</u>	95.7/93.2
Toothbrush	51.8/48.6	48.0/ 58.3	<u>69.5</u> /53.9	52.5/33.8	61.8/ <u>54.9</u>	75.2 /50.0
Light	62.0/52.6	41.2/55.8	48.0/52.4	<u>68.5</u> /55.8	37.0/ <u>67.1</u>	69.0/80.3
Mean	<u>68.3</u> /56.5	57.2/57.3	55.5/51.6	56.3/48.3	57.7/ <u>67.7</u>	75.6/77.3



Figure 7: Visualization of data in MiniShift between four defect types and 12 categories. The first row illustrates the high-resolution point clouds, and the second row presents their corresponding ground truth annotations. Defect regions are magnified to enable clearer visual observation.

Table 9: **Quantitative Results on MiniShift-Medium**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$\begin{array}{l} \text{Method} \rightarrow \\ \text{Category} \downarrow \end{array}$	PatchCore-FP CVPR'22	PatchCore-PM CVPR'22	PatchCore-PB CVPR'22	R3D-AD ECCV'24	GLFM TASE'25	Simple3D Ours
Capsule	88.8/55.2	48.8/54.5	35.0/49.3	50.0/54.6	38.2/59.7	97.2/84.2
Cube	63.2/55.7	36.0/51.1	34.2/51.8	58.3/55.9	49.5/65.0	59.0/ 69.2
Spring pad	68.0/53.3	47.0/51.7	43.7/50.5	46.8/46.6	54.2/49.7	69.3/64.6
Screw	25.0/60.3	62.0/48.5	<u>67.5</u> /45.9	53.8/48.8	72.2/50.1	25.8/56.9
Screen	71.2/53.8	69.5/48.6	54.8/49.3	59.0/50.6	71.2/67.3	66.5/55.1
Piggy	<u>60.0/59.0</u>	52.3/53.2	44.5/46.7	54.8/51.5	56.2/55.1	72.2/67.6
Nut	<u>71.5</u> /52.7	58.8/52.2	49.5/51.4	56.0/47	42.8/54.1	79.0/70.3
Flat pad	59.8/54.6	<u>63.5</u> /57.0	40.2/52.6	54.3/52.8	58.2/ <u>58.7</u>	65.2/60.9
Plastic cylinder	<u>83.5</u> /57.3	79.0/58.6	42.5/51.2	34.5/51.1	65.5/ <u>61.5</u>	86.0/69.4
Button cell	<u>85.5</u> /54.6	65.8/49.2	50.8/47.8	49.8/51.6	58.8/ <u>62.3</u>	90.5/73.3
Toothbrush	52.2/46.1	48.8/54.1	<u>54.8</u> / 54.2	33.0/45.4	52.8/45.8	59.7 /45.1
Light	<u>59.0</u> /46.4	37.7/52.6	42.0/53.4	59.3 /52	40.5/58.1	53.0/ 69.9
Mean	<u>65.6</u> /54.1	55.8/52.6	46.6/50.3	50.8/50.7	55.0/ <u>57.3</u>	68.6/65.5

Table 10: **Quantitative Results on MiniShift-Hard**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$Method \rightarrow$	PatchCore-FP	PatchCore-PM	PatchCore-PB	R3D-AD	GLFM	Simple3D
Category \downarrow	CVPR'22	CVPR'22	CVPR'22	ECCV'24	TASE'25	Ours
Capsule	75.5/54.4	44.7/50.0	40.2/49.4	56.0/50.6	39.2/ <u>61.6</u>	81.5/62.8
Cube	59.8 /52.4	34.2/52.6	40.2/51.9	55.8/ 57.4	37.2/54.2	<u>54.3/55.7</u>
Spring pad	67.8/52.1	48.5/53.0	36.2/49.6	38.3/48.4	63.2/ <u>54.8</u>	<u>64.5</u> / 55.5
Screw	25.0/52.6	56.8/54.2	63.5/52.9	34.5/48.1	<u>59.0/54.8</u>	18.8/ 57.9
Screen	<u>69.8</u> /51.0	64.5/56.3	62.8/58.1	39.3/53.2	60.8/ 59.3	70.5/51.5
Piggy	62.0/ <u>50.1</u>	<u>62.2</u> /48.5	65.8/46.7	56.3/45.7	58.0/39.0	60.2/ 52.9
Nut	<u>62.0</u> /54.7	61.8/48.5	51.5/51.2	60.8/53.9	53.5/ <u>59.3</u>	66.0/62.4
Flat pad	60.0/53.7	63.8/59.4	54.0/50.7	45.8/50.7	62.5/51.3	63.3/59.2
Plastic cylinder	75.5/ <u>51.1</u>	67.0/50.9	59.2/45.5	51.0/47.0	62.8/49.1	<u>72.2</u> / 58.0
Button cell	<u>78.0</u> /50.8	65.0/48.2	62.8/46.7	31.8/ <u>54.6</u>	59.8/53.0	83.8/56.5
Toothbrush	42.5/45.9	45.5/ 59.5	48.2/58.0	<u>61.5</u> /37.6	45.8/44.1	63.2/41.7
Light	58.5 /44.3	38.0/42.9	49.8/49.4	<u>56.8/54.3</u>	32.2/52.1	40.8/ 61.4
Mean	<u>61.4</u> /51.1	54.3/52.0	52.9/50.8	50.1/50.6	52.8/ <u>52.7</u>	61.6/56.3

$\begin{array}{l} \text{Method} \rightarrow \\ \text{Real3D-AD} \end{array}$	CPMF PR'24	Reg3D-AD NeurIPS'23	Group3AD ACM MM'24	IMRNet CVPR'24	ISMP AAAI'25	GLFM TASE'25	PO3AD CVPR'25	MC3D-AD IJCAI'25	Simple3D Ours
Airplane	63.2/61.8	71.6/63.1	74.4/63.6	76.2/-	85.8 / <u>75.3</u>	54.6/74.3	80.4/-	<u>85.0</u> /62.8	76.5/ 88.1
Car	51.8/83.6	69.7/71.8	72.8/74.5	71.1/-	73.1/83.6	<u>84.2/88.2</u>	65.4/-	74.9/81.9	98.1/99.2
Candybar	71.8/73.4	82.7/72.4	<u>84.7</u> /73.8	75.5/-	85.2 /90.7	71.5/79.7	78.5/-	83.0/ <u>91.0</u>	65.1/ 96.2
Chicken	64.0/55.9	85.2 /67.6	78.6/75.9	78.0/-	71.4/ <u>79.8</u>	68.8/62.4	68.6/-	71.5/64.0	<u>82.6</u> / 86.1
Diamond	64.0/75.3	90.0/83.5	93.2/86.2	90.5/-	94.8/92.6	71.2/76.8	80.1/-	<u>95.5/94.2</u>	100/99.0
Duck	55.4/71.9	58.4/50.3	67.9/63.1	51.7/-	71.2/ <u>87.6</u>	94.5 /66.3	82.0/-	<u>83.1</u> /82.2	77.8/ 96.6
Fish	84.0/ 98.8	91.5/82.6	97.6 /83.6	88.0/-	<u>94.5</u> /88.6	69.5/94.2	85.9/-	86.5/93.2	91.2/ <u>96.2</u>
Gemstone	34.9/44.9	41.7/54.5	53.9/56.4	67.4/-	46.8/ <u>85.7</u>	68.8/75.0	<u>69.3</u> /-	56.0/45.8	70.4/97.3
Seahorse	84.3/ 96.2	76.2/81.7	84.1/82.7	60.4/-	72.9/81.3	<u>92.4</u> /81.5	75.6/-	71.6/65.9	93.0 / <u>94.2</u>
Shell	39.3/72.5	58.3/ <u>81.1</u>	58.5/79.8	66.5/-	62.3/ 83.9	73.3/60.2	<u>80.0</u> /-	80.3 /77.8	51.4/71.6
Starfish	52.6/ <u>80.0</u>	50.6/61.7	56.2/62.5	67.4/-	66.0/64.1	74.8/67.5	<u>75.8</u> /-	76.6 /69.0	69.6/ 85.8
Toffees	<u>84.5/95.9</u>	68.5/75.9	79.6/80.3	77.4/-	84.2/89.5	76.3/93.5	77.1/-	73.8/93.4	88.8/96.8
Mean	62.5/75.9	70.4/70.5	75.1/73.5	72.5/-	76.7/ <u>83.6</u>	75.0/76.7	76.5/-	<u>78.2</u> /76.8	80.4/92.3

Table 11: Quantitative Results on Real3D-AD. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.



Figure 8: Visualization of prediction results in MiniShift using the proposed method Simple3D and other methods. The first row is the original point clouds, while the second row is the ground truth. Subsequent rows depict various methods. Defect regions are magnified to enable clearer visual observation.

 $\text{Method} \rightarrow$ M3DM-PM CPMF Reg3D-AD IMRNet ISMP GLFM PO3AD MC3D-AD Simple3D Anomaly-ShapeNet CVPR'23 PR'24 NeurIPS'23 CVPR'24 TASE'25 CVPR'25 IJCAI'25 Ours AAAI'25 35.3/-59.7/-96.2/-Ashtray0 51.9/66.7 67.1/--/60.3 52.8/74.1 100.0/96.2 99.5/92.0 Bag0 55.7/62.8 64.3/-70.6/-66.0/--/74.7 53.7/75.4 83.3/94.9 80.5/-88.1/95.4 Bottle0 49.5/54.5 52.0/-48.6/-55.2/--/77.0 49.5/80.5 90.0/91.2 79.5/-97.6/97.4 Bottle1 55.1/57.8 48.2/-69.5/-70.0/--/56.8 69.9/70.7 93.3/**84.4** 70.9/-**95.1**/72.8 Bottle3 44.1/69.5 40.5/-100/83.8 52.5/-64.0/--/77.5 74.5/85.3 92.6/88.0 75.6/-Bowl0 55.2/62.7 78.3/-67.1/-68.1/--/85.1 53.1/83.0 92.2/97.8 93.0/-100/98.8 Bowl1 41.1/38.4 63.9/-52.5/-70.2/--/54.6 54.3/62.0 82.9/91.4 97.8/-83.0/95.1 Bowl2 45.6/45.8 62.5/-49.0/-68.5/--/73.6 61.0/73.8 83.3/91.8 71.9/-71.1/93.3 Bowl3 40.7/45.9 65.8/-34.8/-59.9/--/77.3 79.4/87.7 88.1/93.5 88.5/-91.1/99.3 Bowl4 47.8/55.9 68.3/-66.3/-67.6/--/74.0 75.1/59.5 98.1/96.7 91.1/-73.0/92.9 Bowl5 61.4/45.7 68.5/-59.3/-71.0/--/53.4 72.0/58.2 84.9/94.1 75.4/-86.3/97.9 Bucket0 53.3/42.1 48.2/-61.0/-58.0/--/52.4 51.2/60.9 85.3/75.5 89.8/-95.9/72.5 Bucket1 43.2/65.9 60.1/-75.2/-77.1/--/67.2 66.2/69.4 78.7/89.9 78.4/-79.0/92.1 Cap0 48.5/68.1 60.1/-69.3/-73.7/--/86.5 62.1/97.6 87.7/95.7 79.3/-85.2/98.8 Cap3 58.6/65.5 55.1/-72.5/-77.5/--/73.4 56.4/89.1 85.9/94.8 70.1/-86.7/96.4 61.1/54.2 55.3/-64.3/-65.2/--/75.3 81.2/92.6 83.5/-91.2/97.9 Cap4 79.2/94.0 Cap5 49.5/50.7 69.7/-46.7/-65.2/--/67.8 64.2/87.2 67.0/86.4 76.1/-80.4/96.4 49.7/-Cup0 51.0/59.8 51.0/-64.3/--/86.9 56.4/73.1 87.1/90.9 74.3/-100/97.9 Cup1 42.4/51.5 49.9/-53.8/-75.7/--/60.0 63.4/55.9 83.3/93.2 95.2/-82.4/93.7 Eraser0 50.0/50.0 68.9/-34.3/-54.8/--/70.6 55.7/60.9 99.5/97.4 77.6/-100/97.0 Headset0 49.8/50.4 64.3/-53.7/-72.0/--/58.0 59.2/72.6 80.8/82.3 <u>86.2</u>/-98.2/93.6 Headset1 50.0/55.7 45.8/-61.0/-92.3/90.7 67.6/--/70.2 63.4/60.8 88.6/-95.7/95.8 Helmet0 55.5/-60.0/-59.7/-67.2/-41.7/53.1 -/68.3 59.3/75.3 **76.2**/87.8 69.0/**90.2** Helmet1 50.0/47.3 58.9/-38.1/-60.0/--/62.2 <u>96.1</u>/**94.8** 100/-71.9/90.2 62.8/62.6 Helmet2 55.1/66.4 46.2/-61.4/-64.1/--/84.4 56.5/81.8 86.9/<u>93.2</u> 60.9/-75.4/94.7 Helmet3 50.9/57.3 52.0/-36.7/-57.3/--/72.2 53.8/72.8 97.9/-75.4/84.6 65.5/92.8 78.0/-44.3/69.5 61.0/-59.2/-56.9/74.9 97.1/-Jar0 -/82.3 86.6/87.1 90.5/97.8 Microphone0 53.3/59.7 50.9/-41.4/-75.5/--/66.1 71.9/81.4 77.6/81.0 91.9/-100/96.4 Shelf0 46.7/66.5 68.5/-68.8/-60.3/--/<u>68.7</u> 57.0/64.4 57.3/66.3 84.1/-<u>74.8</u>/90.1 Tap0 47.6/55.2 35.9/-67.6/-67.6/--/52.2 68.9/70.6 74.5/78.3 94.5/-70.3/85.7 Tap1 49.3/45.0 69.7/-64.1/-69.6/--/55.2 68.1/69.2 97.0/-59.6/**81.1** 42.6/78.3 Vase0 52.9/50.7 45.1/-53.3/-82.1/-53.3/--/66.1 67.6/77.8 <u>85.8</u>/95.5 95.4/93.4 Vase1 85.7/-66.2/71.9 34.5/-70.2/-75.7/--/84.3 76.1/93.4 74.2/88.2 82.4/80.7 Vase2 70.0/55.1 58.2/-60.5/-61.4/--/73.3 59.3/61.4 95.2/97.8 92.9/-87.1/98.6 Vase3 50.9/51.5 58.2/-65.0/-70.0/--/76.2 67.3/76.7 **82.1**/88.4 76.1/-81.2/91.0 Vase4 51.5/44.9 50.0/-51.4/-52.4/--/54.5 57.3/70.5 67.5/90.2 87.6/-86.4/98.5 85.2/<u>93.7</u> Vase5 54.3/49.5 61.8/-52.0/-67.6/--/47.2 54.8/61.5 97.6/-96.2/**96.6** Vase7 60.5/34.1 39.7/-46.2/-63.5/--/70.1 51.3/75.8 **96.6**/98.2 93.8/-89.5/**99.0** Vase8 48.5/50.7 52.9/-62.0/-63.0/--/85.1 66.3/95.2 73.9/95.0 67.0/-85.5/97.5 Vase9 43.6/45.9 60.9/-59.4/-59.4/--/61.5 70.3/74.4 83.0/95.2 73.6/-81.5/91.3 61.9/74.5 55.9/-57.2/-75.7/69.1 84.2/74.8 Mean 51.1/54.9 66.1/65.0 83.9/89.8 86.0/92.9

Table 12: **Quantitative Results on Anomaly-ShapeNet**. The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

Table 13: **Quantitative Results on MulSen-AD.** The results are presented in O-ROC%/P-ROC%. The best performance is in **bold**, and the second best is <u>underlined</u>.

$Method \rightarrow$	M3DM-PM	M3DM-PB	PatchCore-FP	PatchCore-FP-R	PatchCore-PM	IMRNet	Reg3D-AD	GLFM	Simple3D
MulSen-AD	CVPR'23	CVPR'23	CVPR'22	CVPR'22	CVPR'22	CVPR'24	NeurIPS'23	TASE'25	Ours
Capsule	73.1/77.7	67.1/75.3	89.8/91.7	90.5/91.9	90.3/92.1	60.1/42.3	91.2/87.7	<u>96.7/93.0</u>	98.1/97.3
Cotton	56.8/66.3	<u>80.5</u> / 69.9	25.3/55.4	26.3/54.6	19.7/52.8	58.5/50.7	43/52.1	81.2 / <u>67.9</u>	78.8/60.2
Cube	46.3/61.3	45.8/ <u>71.0</u>	72.3/57.5	66.8/43.7	72.2/41.7	43.2/56.6	56.9/62.6	<u>75.6</u> /68.0	82.7/73.2
Spring pad	69.8/56.8	51.7/65.2	98.6/62.9	100 /60.1	96.5/62.1	65.1/40.1	95.1/ <u>80.2</u>	100 /70.5	100/81.1
Screw	66.3/45.3	95.5/44.3	<u>97.9</u> /57.8	93.1/ <u>61.0</u>	99.7 /59.7	74.2/45.6	97.2/54.0	63.6/60.9	86.4/ 74.7
Screen	90.6/52.9	<u>92.8</u> /56.7	91.6/ 60.9	95.0 / <u>58.7</u>	89.7/53.2	37.8/35.2	64.1/46.6	86.6/50.8	73.8/52.9
Piggy	16.4/61.7	44.7/57.2	100/ <u>84.8</u>	<u>99.7</u> /62.4	98.2/60.3	72.9/51.2	86.6/63.5	73.2/77.8	89.6/ 91.6
Nut	78.3/63.1	75.1/68.7	97.1/90.3	98.9 /89.6	98.9 /89.7	81.2/36.9	79.7/80.7	94.0/ <u>95.7</u>	96.9/ 97.2
Flat pad	88.5/62.6	77.2/58.3	100 /70.7	89.3/67.8	94.4/63.0	71.4/54.2	90.8/69.2	94.6/ <u>77.2</u>	100/82.0
Plastic cylinder	46.2/51.0	70.6/65.2	<u>94.1/83.0</u>	90.8/76.6	93.6/76.9	62.1/41.2	76.5/67.0	81.5/67.8	99.4/96.4
Zipper	70.1/49.6	69.8/ <u>56.3</u>	79.7/55.2	<u>81.3</u> /54.5	73.9/50.2	63.0/49.6	47.0/53.6	<u>81.3</u> / 57.4	88.5 /53.0
Button cell	54.9/79.7	65.9/ <u>79.9</u>	91.5 /38.2	68.7/51.2	79.7/47.8	70.2/48.5	78.2/70.6	56.7/43.3	<u>85.1</u> / 80.1
Toothbrush	80.3/50.1	<u>90.1</u> /38.6	90.5 /60.5	88.8/60.4	89.1/ <u>60.6</u>	61.5/51.9	81.2/47.2	84.9/57.8	82.9/ 73.3
Solar panel	38.5/53.9	39.5/60.1	62.4/20.2	60.5/26.5	61.2/27.4	34.4/53.3	66.0 / <u>60.9</u>	40.9/57.5	<u>64.4</u> / 94.9
Light	57.9/48.0	65.3/49.5	97.5/ <u>70.7</u>	100 /70.6	<u>99.2</u> /69.6	45.7/41.5	89.7/65.1	66.1/52.6	96.8/ 95.9
Mean	62.8/58.7	70.5/61.1	<u>86.0</u> /64.0	83.3/62.0	84/60.5	60.1/46.7	74.9/64.1	78.5/ <u>66.5</u>	88.2/80.3